

Fence Assembly Instructions for the Homeowner/Do-it-yourselfer

1. First you must find a level spot to assemble your panels. Using a standard picnic table, sawhorses with plywood, or any other type of table will work just fine.
2. Lay out two of the routed post approximately six feet apart on top of your assembly surface. Keep in mind to protect these post because you will need these later in the final installation of your new fence.
3. Next you will insert two/three of the stringer/header components into the routed holes in the post. These need to be inserted until the notch portion comes into contact with the post.
**NOTE: It would be wise at this point to secure the posts to your assembly surface. This can be done by using padded C-clamps, speed clamps, or any other type of clamping system.
4. Now slide the pickets into the corresponding holes in the stringers. You can reference the drawing which coincides with your particular style of fence.
5. Once you've inserted the pickets, use a tape measure to confirm their position to the corresponding rail by referencing the drawing.
6. Once you have the pickets in the correct position, insert a screw through the hole in the rail to securely fasten the picket to the rail. Continue this process until all pickets are securely fastened.
7. When you have completed fastening all pickets to the rails, you can remove the clamps from the posts and then remove your completed panel from the table.
8. Repeat this process until all panels have been completed.