


OPTIONAL: WEATHERGUARD™ KENNEL COVER AND FRAME INSTALLATION INSTRUCTIONS



Parts L-O

Hi-Rise 5'x5' 10'x5' 15'x5' 10'x10'

L	A-Frame Gable Supports	2	2	3	4	3
M	Two-Way End Clamps	2	2	2	2	2
N	Three-Way Center Clamps	0	0	1	2	1
O	Center Ridge Poles	1	1	2	3	2
P	Elastic Tie Downs (not shown)	8	8	12	14	14

STEP #1

Insert A-frame gable supports (Part L) into top of corner stands (Part C and Part D) and center stands (Part G). Slide ends of tubing down as far as possible.


STEP #2

Install the two-way end clamps (Part M) at the center of each A-frame gable support (Part L) that rests on corner stands (Figure 1). If installing on a 10' or 15' long kennel, install three-way center clamp (Part N) at the center of A-frame gable supports that rests on center stands (Figure 2). Center ridge pole (Part O) between A-frame gable supports and tighten (Figure 3).

STEP #3

Unfold kennel cover material and drape over kennel cover frame. Secure with elastic tie downs (Part P - not shown).

Hint! Avoid over stretching the tie downs as it could cause damage to grommets.



To purchase a Weatherguard™ Kennel Cover for your Lucky Dog™ Kennel contact customer service at 1.800.955.2879